



ATELIER VALS

SWISS INSPIRED. KENTUCKY MADE.

Vals Stone Cleaning and Care

When pallets are delivered to the site, keep covered with a tarp, plastic, or house wrap to keep debris, acid rain, and other natural elements from streaking the stone while it is palletized. Do not stack pallets onsite. Refrain from criss-cross stacking the pavers, as this will keep them from curing evenly.

Our Smooth and Thermal textured pavers will ship on a covered/tarped truck. You may need to have equipment onsite to offload for the smooth and thermal textured pavers. This will be communicated and arranged through our Touch System.

When installing the stone, keep excess soil debris, foot traffic, and other construction debris off the newly installed product until it is properly cleaned and sealed. We recommend construction fencing around the newly installed areas. Clean Vals Stone with a cleaning mixture of 1/2 cup Dawn dish soap to 4 gallons of water. If that does not clean sufficiently. Clean with mixture of 1/2 gallons of Outdoor Clorox to 4 gallons of water. Let the mixture work for 6-8 minutes depending on the depth of the dirt and rinse thoroughly 2 times. If more cleaning would be needed call Atelier Vals for instructions at 502-498-0840

Pavers should be washed prior to sealer application. Allow pavers to dry before applying sealer. Sealer should be applied in temperatures above 50 degrees and should dry between 2-4 hours depending on weather conditions. We recommend sealing on a sunny day.

Sealer should not be stored in temperatures under 42 degrees or it will freeze and ruin. Please make sure sealer is stored in an area that will not be exposed to cold temperatures, until ready for use.

If these procedures are followed, your final cleanup will be swift and your project will be even more beautiful. We appreciate your business and please reach out if you have any questions.

July 2024